# **3-Phase systems**

Day 27

3-Phase power


# ILOs – Day 27


- Derive the power equations in 3-phase balanced system
- Explain and apply the 2-wattmeter method for measurement of 3-phase power
- Understand the effect of power factor on wattmeter readings in 2-wattmeter method for measurement of 3-phase power

### Three phase power in Star connected system

#### Consider the system to be balanced

- Phase voltages are equal and 120° apart
- Phase currents are also equal and 120° apart






#### Total 3-phase active power (Watt)


$$P = 3 \times (V_{ph} \times I_{ph} \times \cos \theta)$$
$$= 3 \times \frac{V_L}{\sqrt{3}} \times I_L \times \cos \theta$$
$$= \sqrt{3} V_L I_L \cos \theta$$

# Three phase power in Delta connected system

#### Consider the system to be balanced

- Phase voltages are equal and 120<sup>o</sup> apart
- Phase currents are also equal and 120° apart






#### Total 3-phase active power (Watt)


$$P = 3 \times (V_{ph} \times I_{ph} \times \cos \theta)$$
$$= 3 \times V_L \times \frac{I_L}{\sqrt{3}} \times \cos \theta$$
$$= \sqrt{3}V_L I_L \cos \theta$$


### Three phase power



Irrespective of the type of connection, star or delta, the power delivered (or consumed) remains same for a given three phase system

### Three phase powers





$$P = \sqrt{3}V_L I_L \cos \theta$$

Active power (W)

$$P = \sqrt{3}V_L I_L \cos \theta$$

$$Q = \sqrt{3}V_L I_L \sin \theta$$
 Reactive power (VAr)

$$Q = \sqrt{3}V_L I_L \sin \theta$$

$$S = \sqrt{3}V_L I_L$$
$$= P + jQ$$

Apparent (total) power (VA)

$$S = \sqrt{3}V_L I_L$$
$$= P + jQ$$


$$= \sqrt{P^2 + Q^2}, \angle \tan^{-1} \frac{Q}{P}$$

$$= \sqrt{P^2 + Q^2}, \angle \tan^{-1} \frac{Q}{P}$$

Power factor, 
$$\cos \theta = \frac{P}{S} = \frac{\text{Active power}}{\text{Appartent power}}$$

#### Measurement of power


- A wattmeter is used to measure active power
- Thus, it has to measure voltage and current both at the same time
- Thus, a wattmeter has two measuring coils
- One is current coil (CC) connected in series with the line to measure current
- •The other is the voltage coil or pressure coil (PC) connected across the line (parallel) to measure the voltage



#### Measurement of power

• Wattmeter reads average active power,  $P = VIcos\theta$ 


• P = (PC voltage)×(CC current) ×(Cosine of angle between PC & CC)  $V \qquad I \qquad cos\theta$ 



#### Measurement of three phase power


#### Two-wattmeter method in 3-phase 3-wire circuit

(the basic process is same for both delta or star connected system. The example is shown for a star connected system)



- The current coils of the two wattmeters W<sub>1</sub> and W<sub>2</sub> are connected in lines R and B
- Voltage coil of W<sub>1</sub> is connected between lines R and Y
- Voltage coil of W<sub>2</sub> is connected between lines B and Y


#### Measurement of three phase power



Reading of wattmeter  $W_1$ :  $P_1 = V_{RY} \times I_R = (V_{RN} - V_{YN}) \times I_R$ 

Reading of wattmeter  $W_2$ :  $P_2 = V_{BY} \times I_B = (V_{BN} - V_{YN}) \times I_B$ 

## Measurement of three phase power



- It can thus, be concluded that, sum of the two wattmeter readings is equal to the total 3phase power consumed by the load
- This is irrespective of fact whether the load is balanced or not.

Summation of the two wattmeter readings:

$$\begin{split} P_1 + P_2 &= \left(V_{RN} - V_{YN}\right) \times I_R + \left(V_{BN} - V_{YN}\right) \times I_B \\ &= V_{RN} \times I_R + V_{BN} \times I_B - V_{YN} \times \left(I_R + I_B\right) \end{split}$$


**Total 3-phase power** 

$$=V_{RN} \times I_R + V_{BN} \times I_B + V_{YN} \times I_Y$$

From KCL, summation of currents at node N must be zero, i.e.

$$I_R + I_Y + I_B = 0$$

$$I_R + I_B = -I_Y$$



Phase voltages are 120<sup>o</sup> apart:


$$V_{RN}, V_{BN}, V_{YN}$$

Line voltages V<sub>RY</sub> and V<sub>BY</sub>

$$\overline{V}_{\mathit{RY}} = \overline{V}_{\mathit{RN}} - \overline{V}_{\mathit{YN}} \qquad \overline{V}_{\mathit{BY}} = \overline{V}_{\mathit{BN}} - \overline{V}_{\mathit{YN}}$$


Let, power factor =  $\cos\theta$ 

#### **Phasor diagram:**



i.e. phase currents lag corresponding phase voltages by  $\boldsymbol{\theta}$ 

Currents are also balanced and are 120° apart:




- •Current through the CC of wattmeter  $W_1$  is  $I_R$  and voltage across its potential coil is  $V_{RY}$
- •The current  $I_R$  leads the voltage by  $V_{RY}$  an angle (30°- $\theta$ )


Line voltages  $V_{RY} = V_{YR} = V_{RR} = \sqrt{3}V$ 

Line currents  $I_R = I_R = I_V = I$ 


... Reading of wattmeter  $W_1$  is:  $P_1 = V_{RY} \times I_R \cos(30^\circ - \theta) = \sqrt{3}VI\cos(30^\circ - \theta)$ 



- Current through the CC of wattmeter
   W<sub>2</sub> is I<sub>B</sub> and voltage across its
   potential coil is V<sub>BY</sub>
- The current  $I_B$  lags the voltage by  $V_{BY}$  an angle  $(30^0+\theta)$



 $\therefore$  Reading of wattmeter W<sub>2</sub> is:  $P_2 = V_{BY} \times I_B \cos(30^0 + \theta) = \sqrt{3}VI\cos(30^0 + \theta)$ 



$$P_1 = \sqrt{3}VI\cos(30^0 - \theta)$$

$$P_2 = \sqrt{3}VI\cos(30^0 + \theta)$$

Sum of these two wattmeter readings:

$$P_{1} + P_{2} = \sqrt{3}VI\cos(30^{0} - \theta) + \sqrt{3}VI\cos(30^{0} + \theta)$$

$$= \sqrt{3}VI \begin{bmatrix} \cos 30^{0}\cos \theta + \sin 30^{0}\sin \theta \\ + \cos 30^{0}\cos \theta - \sin 30^{0}\sin \theta \end{bmatrix}$$

$$= \sqrt{3}VI \begin{bmatrix} 2\cos 30^{0}\cos \theta \end{bmatrix}$$

$$= \sqrt{3}VI \begin{bmatrix} 2\cos 30^{0}\cos \theta \end{bmatrix}$$

$$= \sqrt{3}VI \begin{bmatrix} 2\cos 30^{0}\cos \theta \end{bmatrix}$$

$$= 3VI\cos \theta$$

This is the total active power consumed by the load, adding together power in the three individual phases

Thus, summation of the two wattmeters gives total 3-phase power

$$P_1 = \sqrt{3}VI\cos(30^0 - \theta)$$

$$P_2 = \sqrt{3}VI\cos(30^0 + \theta)$$

Sum of these two wattmeter readings:

$$P_1 + P_2 = 3VI\cos\theta$$

Difference of these two wattmeter readings:

$$P_1 - P_2 = \sqrt{3}VI\cos(30^0 - \theta) - \sqrt{3}VI\cos(30^0 + \theta) = \sqrt{3}VI\sin\theta$$

Taking the ratio:

$$\frac{P_1 - P_2}{P_1 + P_2} = \frac{\sqrt{3}VI\sin\theta}{3VI\cos\theta} = \frac{\tan\theta}{\sqrt{3}}$$

$$\theta = \tan^{-1}\left(\sqrt{3}\frac{P_1 - P_2}{P_1 + P_2}\right)$$

Thus, power factor

$$\cos\theta = \cos\left[\tan^{-1}\left(\sqrt{3}\frac{P_1 - P_2}{P_1 + P_2}\right)\right]$$

$$P_1 = \sqrt{3}VI\cos(30^{\circ} - \theta)$$
  $P_2 = \sqrt{3}VI\cos(30^{\circ} + \theta)$   $\cos\theta = \cos\left|\tan^{-1}\left(\sqrt{3}\frac{P_1 - P_2}{P_1 + P_2}\right)\right|$ 

With unity power factor:  $\cos \theta = 1$ ,  $\theta = 0$ 

Total power: 
$$P = P_1 + P_2 = 3VI\cos\theta = 3VI \leftarrow$$

Reading of wattmeter W<sub>1</sub> 
$$P_1 = \sqrt{3}VI\cos(30^\circ - \theta) = \sqrt{3}VI\cos(30^\circ - \theta) = \sqrt{3}VI\cos(30^\circ - \theta)$$

Reading of wattmeter W<sub>2</sub> 
$$P_2 = \sqrt{3}VI\cos(30^0 + \theta) = \sqrt{3}VI\cos(30^0 + \theta)$$

Thus, summation of two wattmeter readings: 
$$P_1 + P_2 = \frac{3}{2}VI + \frac{3}{2}VI = 3VI$$

Which is same as the total power

- Thus, at unity power factor, readings of the two wattmeters are equal
- Each wattmeter reads half the total power

$$P_1 = \sqrt{3}VI\cos(30^{\circ} - \theta)$$
  $P_2 = \sqrt{3}VI\cos(30^{\circ} + \theta)$   $\cos\theta = \cos\left[\tan^{-1}\left(\sqrt{3}\frac{P_1 - P_2}{P_1 + P_2}\right)\right]$ 

With 0.5 power factor:  $\cos \theta = 0.5$ ,  $\theta = 60^{\circ}$ 

$$\cos \theta = 0.5, \theta = 60^{\circ}$$

Total power: 
$$P = P_1 + P_2 = 3VI\cos\theta = 3VI\cos60^0 = \frac{3}{2}VI$$

Reading of wattmeter W<sub>1</sub>  $P_1 = \sqrt{3}VI\cos(30^{\circ} - \theta) = \sqrt{3}VI\cos(30^{\circ} - 60^{\circ}) = \sqrt{3}VI\cos(30^{\circ} - 60$ 

Reading of wattmeter W<sub>2</sub>  $P_2 = \sqrt{3}VI\cos(30^0 + \theta) = \sqrt{3}VI\cos(30^0 + 60^0) = \sqrt{3}VI\cos(90^0 = 0)$ 

Thus, summation of two wattmeter readings:  $P_1 + P_2 = \frac{3}{2}VI + 0 = \frac{3}{2}VI$ 

Which is same as the total power

- Thus, at 0.5 power factor, one of the two wattmeters reads zero
- The other wattmeter reads total power

$$P_1 = \sqrt{3}VI\cos(30^{\circ} - \theta)$$
  $P_2 = \sqrt{3}VI\cos(30^{\circ} + \theta)$   $\cos\theta = \cos\left[\tan^{-1}\left(\sqrt{3}\frac{P_1 - P_2}{P_1 + P_2}\right)\right]$ 

With 0 power factor:  $\cos\theta = 0$ ,  $\theta = 90^{\circ}$ 

$$\cos\theta = 0, \theta = 90^{\circ}$$

Total power: 
$$P = P_1 + P_2 = 3VI\cos\theta = 3VI\cos 90^0 = 0$$

Reading of wattmeter 
$$W_1$$
  $P_1 = \sqrt{3}VI\cos(30^{\circ} - \theta) = \sqrt{3}VI\cos(30^{\circ} - 90^{\circ}) = \sqrt{3}VI\cos(-60^{\circ}) = \frac{\sqrt{3}}{2}VI\cos(-60^{\circ}) = \frac{\sqrt{3}}{2}VI\cos(-60^$ 

Reading of wattmeter W<sub>1</sub> 
$$P_1 = \sqrt{3}VI\cos(30^{\circ} - \theta) = \sqrt{3}VI\cos(30^{\circ} - 90^{\circ}) = \sqrt{3}VI\cos(-60^{\circ}) = \frac{\sqrt{3}}{2}VI$$
  
Reading of wattmeter W<sub>2</sub>  $P_2 = \sqrt{3}VI\cos(30^{\circ} + \theta) = \sqrt{3}VI\cos(30^{\circ} + 90^{\circ}) = \sqrt{3}VI\cos(20^{\circ} + 90^{\circ}) = \sqrt{3}VI\cos(20^{$ 

Thus, summation of two wattmeter readings: 
$$P_1 + P_2 = \frac{\sqrt{3}}{2}VI - \frac{\sqrt{3}}{2}VI = 0$$

Which is same as the total power

- Thus, at zero power factor, readings of the two wattmeters are equal but of opposite sign
- At power factors below 0.5, one of the wattmeters tends to give negative readings

Pf (cosθ)	Pf angle (θ)	Remarks
1	00	P1 = P2 Total power = 2P1
1> pf > 0.5	$0^{0} < \theta < 60^{0}$	P1 > P2 Total power = P1 + P2
0.5	60 <sup>0</sup>	P1 = +ve, P2 = 0 Total power = P
0.5 > pf > 0	$60^{\circ} < \theta < 90^{\circ}$	P1 = +ve, $P2 = -veTotal power = P1 - P2$
0	900	P1 = - P2 Total power =0